

# WS/GK-1935

Primary Field Shelter



**WESTERN  
SHELTER** SYSTEMS

## TABLE OF CONTENTS

A.	Warnings	3	4.	Lowering the Frame	14
B.	Shelter Specifications	4	5.	Removing Vent Caps	14
C.	Component List	4	6.	Folding Roof Panels	14
D.	Erecting the Shelter	5	7.	Striking the Frame	16
1.	Unpacking the Shelter	6	F.	Troubleshooting	17
2.	End Frame Assembly	6	1.	Frame Connections	17
3.	Center Frame Assembly	6	2.	Wall Panels	17
4.	Roof Assembly	7	3.	Roof Panels	17
5.	Raising the Frame	8	4.	Torn or Worn Vinyl	17
6.	Floor and Basebars	8	5.	Parts will not fit in case	17
7.	Hanging the Doors	9	G.	Tips, Care, and Repair	18
8.	Hanging Shelter Walls	9	1.	Vinyl Panels	18
9.	High Wind Tiedowns	10	2.	Insulation Panels	18
10.	Finishing the Shelter	11	3.	Mainframe and Bars	18
E.	Striking the Shelter	12	4.	Hinges and Pull-Pins	18
1.	Removing Wall Panels	12	5.	Cases and Lids	18
2.	Folding Wall Panels	12	6.	Vinyl Repair	19
3.	Folding Floor Panels	13	7.	Replacement Parts	19

## CONDITIONAL WARRANTY

Western Shelter Systems warrants all products against defects in materials or workmanship for a period of one (1) year from date of manufacture. Component manufacturers' warranties may exceed that of Western Shelter.

No warranty is made or implied regarding the intended use of the product. Warranty does not cover damage caused by abuse, misuse, neglect or improper care by the end user in the application of the Western Shelter Systems product.

Western Shelter Systems will repair or replace any component deemed to be faulty from manufacture in the most efficient and timely means available to Western Shelter Systems.

Western Shelter Systems must authorize all claims prior to any action taken by the end user.

For immediate attention regarding any defective product, please phone Customer Support at 1-800-971-7201, 7am-330pm PST.

Shipping: 815 Conger St. Eugene, OR 97402  
PO Box 2729 Eugene, OR 97402 USA  
Phone 1-541-344-7267  
Toll Free 1-800-971-7201  
Fax 1-541-284-2820  
[www.WesternShelter.com](http://www.WesternShelter.com)

## A. WARNINGS



Follow all written and common sense safety procedures when raising, striking, and occupying this shelter. Failure to do so may result in property damage or personal injury.



All flammable materials or other items that are potential fire hazards must not be placed on or adjacent to the Shelter.



Pinch hazard: Always wear gloves when raising or striking the shelter. Setup entails working with rigid metal components bearing significant weight.

## B. SHELTER SPECIFICATIONS

### **Frame Specifications**

All-aluminum frame constructed of 6063-T5 and 6061-T6 alloys with clear industrial anodized support members.

Octagonal frame configuration, pivoting from a central fixture. Roof trusses and uprights shall be one assembly.

Eave bars and base bars shall lock and unlock into the mainframe with integral spring-loaded buttons, requiring no tools for assembly. Eave bars and base bars shall have a clear anodized finish.

Eave bars shall be of an extruded design to accommodate rigid hook-and-loop fastening strips for the attachment of roof and sidewalls.

Upright legs shall lock either up or down with a steel captive locking pin. Legs shall have a flat foot with provisions for securing to the ground or floor surface. Legs shall provide a full 6-foot sidewall.

The frame assembly shall include vented weather caps.

Doors shall be aluminum framed and fabric covered.

### **Cover Specifications**

The entire cover shall be of 14-oz vinyl-covered polyester scrim.

The material shall meet NFPA-701 standards for fire resistance.

The material shall contain ultra-violet ray and mildew inhibitors.

Roof panel sections shall be thermo-welded to insure against leakage.

All fabric security to the frame shall be by the hook-and-loop fastening process.


## C. COMPONENT LIST

### GK1935, basic configuration:

1. Mainframe end sections (2)
2. Mainframe center section (1)
3. Eave bars with fastening strips (12)
4. Base bars without fastening strips (12)
5. Plastic vent caps (2)
6. Double doors (2)
7. Threshold ramps (2)
8. Vinyl roof panel (1)
9. Insulated roof panel (1) not pictured
10. Vinyl wall panels (4)
11. Vinyl floor panel (1)
12. High wind stake kit with straps (1) not pictured

### GK1935, common accessories:

1. Insulated wall panels (4)
2. Fluorescent lights with dimmer sleeves (7)
3. Wiring harness (4)



## D. ERECTING THE GK1935 SHELTER

### 1. Unpack and inventory shelter components

➤ In a clear staging area, unpack and inventory the shelter components. Check components against case labels or the component list in this manual to ensure you have all required parts.

➤ **Note:** Component list reflects one GK1935 shelter in its basic configuration. Your shelter system may include additional fixtures or accessories.

### 2. Mainframe end section assembly

➤ Locate and prepare your shelter site. Stand up one mainframe end section at one end of the shelter site. Loosen the web strap from around its base.

➤ Orient the open slot on the key flange (without a roof truss) toward the opposite end of the shelter site.

➤ Open up the mainframe until the trusses are fully unfolded.

➤ This is best accomplished with three people, each holding two trusses.

➤ Depress the locking button on the underside of each truss to extend them. The lower



locking button will snap into place when the trusses have reached their full extension.

➤ Secure five eave bars between the roof trusses, with the black fastening strip facing out. If the shelter is on uneven ground, you may have to adjust the frame slightly to get a fit.



➤ Repeat the above steps to erect the second end section, facing the first, at the opposite end of the shelter site.



### 3. Mainframe center section assembly



➤ Attach eave bars to the two corner blocks on one of the mainframe end sections.



➤ With three people, move the second end section to meet the first. Line up the eave bars with the open corner blocks on the second section.

➤ Join the two sections.





- Position the main frame center section between the two end sections.
- The center section has six trusses, four telescoping and two fixed. Orient the center section so that the two fixed trusses are pointed toward the end sections.
- Use the captive locking pins to connect the center section to the key flanges.



- Partially extend the four telescoping roof trusses of the center section. They slip over the center eave bars and share the same locking buttons. Adjust the frame slightly if the buttons do not pop back into place.



- Lift the center section until the locking buttons on all four telescoping roof trusses snap into place.



- To drop the shelter legs, gently squeeze the folded legs and roof trusses together to loosen their captive locking pins. Remove the pins and gently lower all the shelter legs to the ground. Do not stand up the shelter at this point.



#### 4. Roof assembly

- Remove the insulated roof panel from its bag and place it on the center ridge line of the frame.
- Unfold the panel along the ridge line, toward the key flange on each mainframe end section. Position the holes in either end of the panel over the key flange pipes.



- If setting up in windy conditions, unroll the side of the insulated panel facing into the wind first.



- Remove the vinyl roof panel from its bag and place it on the center ridge line of the frame. Unfold the roof panel along the ridge line, toward each of the two key flanges.



➤ Do not secure either of the roof panels to the eave bars at this point.

➤ Position one of the vent collars of the roof panel over each key flange pipe.



➤ Remove the protective vinyl squares covering the vent collars. Return these squares to the field bag; they will be needed again when the roof is repacked.

➤ Make sure both collars are centered on their respective key flange pipes.

➤ To install the vent caps, pull on the locking pin, align the cap with the flange pipe and push the cap down until it meets the collar. Release the pin and rotate the vent cap until the pin snaps into place.



➤ Unroll the insulated and vinyl roof panels and lightly attach the fastening strips around the eave bars to prevent wind from displacing the roof.

### 5. Raising the frame

➤ With three people evenly spaced along one long side of the shelter frame, gently raise that side, allowing the legs to fold outward. Be sure to keep fingers clear of the leg hinges as they unfold. If setting up in windy conditions, raise the windward side first.

➤ Lock the four long-side legs into place using the captive locking pins. Do not lock the short-side legs at this time.



➤ Raise the other side of the shelter, allowing the legs to fold down. Lock the four long-side legs into place.



➤ Now extend and lock the short-side legs into place, using the captive locking pins.



### 6. The floor and basebars

➤ The floor panel is designed to form a weather-tight seal with the vinyl walls, protecting the shelter interior against wind and moisture.

➤ Unroll the floor panel down the length of the shelter.

➤ Unfold the floor panel. Ensure that the black fastening strips of the floor are facing up. Center the floor around the perimeter within the shelter frame.





➤ Working around the perimeter of the shelter, gently lift the frame and pull the floor panel under it. Center the shelter legs on the vinyl welds at each corner.



➤ Attach all base bars to the lower legs. You may have to lift or adjust the frame to find a fit. Be sure to keep the floor flat and tight while installing the base bars. The frame will adjust to its true shape as the base bars are locked into position.



## 7. Hanging the doors

➤ The GK1935 shelter includes two double doors, which can be installed on either the long or short sides of the frame.

➤ Remove the door from its protective vinyl bag. Detach the insulated and vinyl roof panel from the eave bar where you will install the door.

➤ Unfold the door and hook it over the desired eave bar. The bottom of the door fits over the base bar. Make sure both top and bottom of the doorframe are firmly attached.



➤ Center the door frame by aligning the center of the frame with the "center door" sticker on the eave bar.



➤ Open the door completely and install the threshold ramp. It will fit snugly over the doorframe.

➤ Reattach the insulated roof panel to the doorframe. Align the seam in the insulated



roof panel with the center of the doorframe.

➤ Repeat for the other door on the opposite side of the shelter.



## 8. Hanging shelter walls

➤ Attach the insulated roof panel to the eave bars using the fastening strips. Align the center seams on the insulation panel with the center door label on eave bars. The insulation panel should completely and evenly overlap the eaves by about 1/2 inch.

➤ Do not attach the vinyl roof at this time. It will be attached after the walls are installed.

➤ GateKeeper walls are composed of four sections. Each is labeled “Right of Door” or “Left of Door,” referring to the position of the panel when viewed from outside the shelter, facing the door.

➤ If your shelter includes insulated wall panels, hang them first. The procedure is identical for both vinyl and insulated walls.

➤ Loosely attach one end of a wall panel to the door frame. Leave some overlap on the door so the wall will be easier to align later. Work around the shelter, tacking the wall up loosely. Get the entire wall tacked up loosely before you begin to tighten it.



➤ Starting at the door, align the black fastening strip on the wall with the corresponding strip on the door. In small sections, pull the wall panel as tightly as possible around the shelter. When complete, repeat this process with the other three panels.



➤ The wall panels end in a large fastening strip. Each pair of wall sections should overlap somewhat, but complete overlap is not necessary. Pull the two wall sections together as tightly as possible. You may have to go around and retighten the wall panels to ensure a good fit. The tighter the fit, the stronger and quieter the shelter.



➤ If you have just installed your insulated wall panels, repeat the above steps for the vinyl wall panels. If you just installed the vinyl wall panels, move on to the next step.



➤ Pull the vinyl roof panel down over the vinyl wall panels, aligning the seams in the vinyl roof panel with the roof trusses. Start at the corners, pulling down firmly to get a good attachment. Then secure the middle of each wall section and work back toward the corners.



## 9. High-wind tiedowns

➤ The high-wind tiedowns can now be hooked onto the shelter legs. Always stake down your shelter, even if you do not anticipate windy conditions.

➤ Detach just the corner of the vinyl roof panel where you will install the tiedown. It is easy to misalign the tiedown hooks, so ensure they



go all the way over the two eave bars and to either side of the shelter leg. The hook will fit snugly without a gap when fitted properly.

- Attach the tiedown strap to a stake, water barrel, sandbag, or other solid object. Apply light tension to the strap, lock the tensioning mechanism, then pull tight.



- Clip the small attached hook to the metal D-ring on the corner of the vinyl roof panel.



- Secure the extra length of strap with small fastening strip.



## 10. Finishing the shelter

- A series of straps are attached to the bottom of each wall panel. Working from inside the shelter, thread these straps under the nearest base bar and connect. Continue around the shelter.
- Secure the double-D ring wall straps by each door. First buckle the strap, then thread the strap through the d-rings and pull tight.



- Attach the fastening strip on either side of the door to form a seal under the threshold ramp.

- Outside the shelter, create a burm in the floor using the black straps located at each corner of the floor.

- Attach the floor to the fastening strips on base of each wall panel to those on the floor. It is not necessary to pull the wall and floor together tightly.



## E. STRIKING THE GK1935 SHELTER

➤ The GK1935 must be repacked properly and in a certain order to ensure the shelter is ready for deployment the next time it is needed.

➤ Clean and dry all wall, roof, and floor panels before folding and bagging them for storage. If this is not practical in the field, all panels should be unpacked, cleaned, dried, and repacked as soon as possible.

### 1. Remove wall panels

➤ Working around the inside perimeter of the shelter floor, unsnap the web straps connecting the walls to the frame and thread them back under the frame.

➤ Separate the fastening strip connecting the walls to the floor.

➤ Working around the outside perimeter of the roof, separate the fastening strip connecting the roof to the vinyl walls.

➤ Unbuckle the corner retaining straps so the floor panel lays flat.

➤ Starting at one of the doors, pull the vinyl wall panels away from the shelter. Fold them hand over hand to prevent the panels from touching the ground. As you remove panels,

place them on the shelter floor for folding.



➤ Remove the four vinyl panels and four insulated panels (if included) and place them inside the shelter.



➤ Remove doors from the frame, fold in half, and return them to their bags.



### 2. Fold wall panels

➤ All GK1935 wall panels are the same size and are folded the same way. Repeat the following procedure for each of the shelter's four wall vinyl panels.

➤ Western Shelter Systems recommends folding wall panels on the shelter floor.

➤ Begin with the wall panel spread flat, with the exterior facing up.

➤ Make sure window and duct panels are securely fastened.

➤ Fold up the lower third of the wall panel (with the floor straps).



➤ Fold the lower half of the wall panel up over the top half.





➤ Starting at the end opposite from the “right of door” or “left of door” label, roll up the wall panel tightly.



➤ Continue rolling until the wall section is in one compact package. Fold the remaining three vinyl wall panels in the same way. Return the wall panels to their labeled field bags for transport and storage.

➤ The insulated wall panels are folded in a similar way, except you will want to start with the interior (white) side of insulation facing upwards. Then fold in thirds starting from the bottom edge, and roll up identically to the



vinyl walls. Return the insulated wall panels to their vinyl storage bags.

### 3. Fold floor panel

➤ Remove and set aside all the shelter base bars.



➤ Move the shelter legs off of the floor, so it can be folded freely.

➤ Begin with the floor spread flat.



➤ Fold both shorter sides of the floor toward the middle to form a rectangle, as pictured.



➤ Fold in the two longer sides so they meet in the middle of the floor.





- Fold the sides to the middle again.
- Fold the sides to the middle a third time.



- Fold one side over the opposite side.
- Working from both ends, fold up the floor panel in arm-length sections until they meet



in the middle. Fold one end over the other to finish folding the floor.

- Place the folded floor panel in its field bag for storage and transport.

#### 4. Lowering the frame

- Remove the captive locking pins from the four legs at the shorter ends of the shelter.



- Fold the four unlocked legs up and nest them together against the roof truss. Squeeze the leg and roof truss together to make it easier to insert the locking pin. Replace the captive pin to lock them in place. The ends of the frame will sag, but this does not damage the frame.

- With four people evenly spaced along a long side of the shelter frame, remove the captive locking pins from the four legs on that side. Gently lower it to the ground. If conditions are windy, lower the upwind side first.

- Remove the captive locking pins from the legs on the other side of the frame, and gently lower it to the ground.



#### 5. Remove vent caps

- Working around the perimeter of the shelter, separate the insulated roof panel from the frame. Push the roof panels up the frame so you can access the vent caps.



- Pull out on the locking pin and lift the vent caps off their key flanges. Return them to their cases for transport and storage.
- To prevent damage to the roof fabric, replace the protective vinyl squares on top of the vent collars.

#### 6. Fold roof panels

- Both roof panels are folded the same way. Repeat the folding procedure for both vinyl and insulated roof panels.
- Western Shelter Systems recommends folding the roof panels while still on the frame. This method will be easier, and gentler to the roof panels than moving them elsewhere.
- Begin with the panels rolled fully down the frame.

- Fold both shorter sides of the roof panel over the vent collars to form a rectangle.



- Fold both shorter ends up to the vent collars again.



- Fold one longer side approximately 6 inches over the centerline of the roof panel, so it covers the vent collars.



- Fold the same side over itself.



- Fold the same side over itself again.



- Fold the opposite side up, making it flush with the side you have already folded.



- Fold the same side over itself.



- Fold the same side over itself again.



- Fold the same side over the top, making a single roll with the vent collars centered on the bottom.

- Begin folding both ends toward the center in arm-length sections.



- At the last fold, bring one end of the panel up over the opposite end to form one complete package.



- Place the folded panel in its field bag for transport and storage.

- The insulated roof panel folds in the same manner.



## 7. Strike the Frame

- Traveling around the perimeter of the frame, nest and hold each leg bar up against its roof truss. While squeezing the leg and roof truss together, insert the locking pin to lock them together.
- A locking button is located on the underside of each of the four telescoping roof trusses on the mainframe center section. Depress these buttons to create slack on the trusses.
- Detach the four center telescoping trusses from the eave bars. Compress the trusses.



- Remove the captive locking pins connecting the center section to the end sections.
- Gather all of the trusses together, and stand the center section up. Tighten the strap around its base to secure the trusses. To help the frame fit better, you may stagger the trusses slightly, so they fold up tighter.
- Remove all eave bars from the mainframe. Place them in a field bag or case.



- On both mainframe end sections, depress the lower locking button on the underside of each roof truss. Slide the trusses back toward the key flange and depress the upper locking buttons to secure them in place.
- Nest the trusses together and stand each mainframe end section up. Tighten a securing strap around the base of each.



- Place the mainframe end sections and the center section in their field bags for transport and storage.
- Storage cases and bags vary depending on your specific setup. Please refer to the printed labels for each case's content.

## F. TROUBLESHOOTING

### 1. A frame connection will not click into place.

- Be sure the connection point is free of debris.
- Gently lift the frame to allow it to find a natural resting position. Lifting to relieve pressure on the connections allows them to fit more easily.
- Firmly tap the connection point with your palm.
- If a button lock is not popping up, try flexing the frame in various directions until it clicks into place.
- Do not use liquid-based lubricants on frame connections, as this will attract more dust and debris, making the connection less functional in the future. Compressed air may be used if necessary to clean connection points.

### 2. Wall panels will not meet in the center.

- Vinyl stretches to varying degrees depending on ambient temperature. The centers of the wall panels may not fully overlap in all conditions, but it should be possible to overlap the walls somewhat in all conditions.
- If the wall sections are not meeting, re-stretch the vinyl starting from the doorframe. Stretch the vinyl in small sections as you work along the wall.



- After several years, vinyl ages and can harden and lose its elasticity. Eventually, the vinyl walls of your shelter may need to be replaced if they are not stretching enough to complete the shelter.

### 3. Roof panel will not fit fully over the frame

- When securing the roof panel, start by securing opposite corners of the roof panel first. Be sure the roof collars are centered on the key flanges.
- As vinyl ages it can harden and lose its elasticity. Eventually, the vinyl walls of your shelter may need to be replaced if they are cracking or not stretching enough to complete the shelter.

### 4. Torn or worn-out vinyl

- See the Vinyl Repair section (page 20) for information on how to fix minor tears and holes in your vinyl panels.

### 5. Shelter components will not fit in their cases.

- Moisture or dirt can add volume to the walls, floor and roof of the shelter. Be sure all surfaces are as clean as possible under the conditions.
- Push as much air as possible out of the walls, roof, and floor as you are folding them.
- Pack rigid items, such as base bars, in the bottom of cases, then fit softer items around them.
- Try changing the orientation of bulky components, such as the end frame assemblies.
- Have several people put their weight on the case lid and secure the latches.

## G. TIPS, CARE, AND REPAIR

- Western Shelter Systems provides protective bags for shipping and storage. Do not drag these bags on the ground.
- Replacing the components in the proper bags or aluminum cases ensures all parts are accounted for and ready for the next deployment.
- Cleaning and drying of your shelter system will extend the life of the shelter and eliminate health issues associated with particulate buildup. Maintenance is best performed when the shelter is being taken down. If the shelter must be packed when wet and/or dusty, It is VERY important that the shelter is cleaned and dried as soon as possible.
- Utilize the following steps to ensure that proper care and maintenance has been performed.

### 1. Vinyl Panels (roof, walls, and floor)

- Clean and fold on a clean surface, such as the shelter floor. Sweep off loose debris. Remove debris from hook and loop fasteners using a rigid brush.
- Clean with a mild solution such as Simple Green™, Tilex™, or 10% bleach water solution.

- Do not saturate the fabric, especially the hook and loop fastener, which tends to retain water even after prolonged drying times.
- Dry thoroughly using towels, leaf blowers or sunlight.

### 2 Insulation Panels (roof & walls)

- Clean and fold on a clean surface, such as the shelter floor. Sweep off loose debris. Remove debris from hook and loop fasteners using a rigid brush.
- Clean with a mild solution such as Simple Green™, Tilex™, or 10% bleach water solution.
- Do not saturate the fabric, especially the hook and loop fastener, which tends to retain water even after prolonged drying times.
- Do not spray cleaner directly on fabric as it could soak into the air bubbles on the fabric, leading to mold and mildew. Spray cleaner on shop towels and wipe to clean.
- Never pressure wash the insulation panels.
- Dry thoroughly using towels, leaf blowers or sunlight.

- **Note:** Stains can occur on the white insulation fabric. These stains, once cleaned, are purely cosmetic and do not indicate product failure or health risks.

### 3. Main Frame, Eave & Base Bars

- Brush off loose debris. Clean dirt and debris out of the ends of the bars and legs. Wipe down with a mild solution such as Simple Green™, Tilex™ or a 10% bleach water solution.
- Dry thoroughly using towels, leaf blowers or sunlight.

### 4. Hinge Points & Pull Pins

- Keep moving parts free of debris and dust. Disassemble and clean if binding occurs.
- Do not use liquid lubricant on moving parts, as this will cause fouling.



## 5. Product Cases & Lids

- Brush off loose debris. Wipe down with a mild solution such as Simple Green™, Tilex™ or a 10% bleach water solution.
- Dry thoroughly using towels, leaf blowers or sunlight, making sure to remove and dry any padding material installed in the bottom of the case.
- Clean dirt and debris out.

## 6. Vinyl Repair

- All units come standard with a vinyl repair kit. Each kit contains a can of vinyl cement and a supply of patching material.
- To repair a damaged area, thoroughly clean with soap and water.
- Allow to dry completely.
- Cut out a piece of vinyl fabric slightly larger than the damaged area.
- Once completely dry, apply a liberal amount of vinyl cement to both the repair area and the patch.

- Allow the cement to become dry to the touch and place the patch over the damaged area. Press the patch firmly to ensure complete contact.

## 7. Replacement Parts and Accessories

- Western Shelter Systems offers a full line of replacement parts, as well as a wide range of optional accessories for all GateKeeper shelters. To view accessories, visit [www.westernshelter.com](http://www.westernshelter.com)